


ID GST80

Part No: 26024

JIG SAW



 Read through carefully and understand these instructions before use..

OPERATION INSTRUCTIONS

SAFETY INSTRUCTION



Warning! When using mains powered tools, basic safety precautions, including the following, should always be followed to reduce the risk of the fire, electric shock, personal injury and material damage.

- ◆ Read all of this manual carefully before operating the tool.
- ◆ Before operating the tool, make sure that you know how to switch the tool off in emergency.
- ◆ Retain this manual for future reference.

GENERAL

1. Work Area Safety

- a. Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- b. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- c. Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

2. Electrical Safety

- a. Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- b. Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- c. Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.

- d. Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep the cord away from the heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- e. When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
- f. If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.

3. Power Tool Use & Care

- a. Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- b. Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- c. Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d. Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users. Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.

Many accidents are caused by poorly maintained power tools.

- e. Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- f. Use the power tool, accessories and tool bits etc. In accordance with these instructions, taking into account the working condition and the work to be performed.

4. Service

- a. Have your power tools serviced by a qualified repair person using only identical replacements parts. This will ensure that the safety of the power tool is maintained.

SAFETY RULES FOR JIG SAW


1. Use only the voltage shown on the nameplate to supply power. Using a voltage higher than shown will increase the rotation speed abnormally and can cause injuries.
2. Hold tool by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord. Contact with a live wire will make exposed metal parts of the tool live and shock the operator. If cutting into existing walls or other blind areas where electrical wiring may exist is unavoidable. Disconnect all fuses or circuit, breakers feeding this work site.
3. Always make sure the work surface is free from nails& other foreign objects, Cutting into a nail can cause the bit and the tool to jump and damage the bit. Never hold the work piece in one hand and the tool in the other hand when in use. Never place hands near or below cutting surface. Clamping the material and guiding the tool with both hands is safer.
4. Remove this unit a safe distance away from electrical conductors when cleaning sections carrying electrical power such as the electrical panel.

- 5. Do not use in locations where inflammable materials such as lacquer, paint, benzene, thinner or gasoline are present. Also do not let items such as lighted cigarette, butts be suctioned inside at such locations. Explosion or fires might result.
- 6. Do not use in environments subject to heavy doses of chemicals, etc. Plastic sections such as the vanes on the inner section of the unit might weaken and break, and injuries might occur.
- 7. If you notice the unit is operating poorly or making abnormal noises, immediately stop using and shut off the power switch. Request an inspection and repair from the dealer where you purchased the unit. Continuing to use while operating abnormally might cause injuries.
- 8. If the unit is mistakenly dropped or strikes another object, make a thorough check of the unit for cracks, breakage or deformation, etc. Injuries might occur if the unit has cracks, breakage or deformation.
- 9. Do not use near objects generating high heat such as stoves. Fires might occur if used near such locations.
- 10. Do not leave on locations such as benches or floors while still rotating. Injuries might occur.

SPECIFICATIONS

Model	ID GST80
Rated Power Input	710W
Rated Voltage	220-240V~
Rated Frequency	50/60Hz
No-load Speed	0-3000r/min
Max. Cutting Diameter	65mm
(Wood)	65mm
(Iron)	6mm
(Aluminium)	10mm


Exploded view of ID GST80



SPECIFICATIONS

Spare Parts List

Part No	Part Description	Part No	Part Description
1	Blade Clip	27	Screw Nut
2	Dust-proof Board	28	Switch
3	Slippery Bearing	29	Variable Speed Board
4	Slip Shank	30	Right Housing
5	Hex Screw	31	Adjusting Button
6	Spring	32	Spring
7	Slippery Bearing of Pendulum	33	Button Lock Pin
8	Shank Fixed Board	34	Safe Mask
9	Slippery Bearing	35	Safe Rack
10	Idle Pulley	36	Excursion Pendulum Pipe
11	Lock Spring	37	Base Board
12	Gear	38	Blade Supporting Pulley
13	Balance Board	39	Pulley Spring
14	Pendulum Board	40	Pendulum Rack
15	Ball Bearing	41	Lock Spring
16	Supporting Rack	42	Pulley Pin
17	Bearing	43	Spring Pin
18	Rotor	44	Pin
19	Bearing	45	Carbon Brush Holder
20	Stator	46	Carbon Brush
21	Inductor	47	Carbon Brush Cover
22	Cable	48	Left Housing
23	Cross Recess Head Tapping Screw	49	Base Board Fix Sheet
24	Strain Relief	50	Washer
25	Exhaust Dust Collection	51	Hex Screw
26	O-Circle	52	Cross Recess Head Tapping Screw



www.idealpowertools.com